

Juno Soundfield System



- The Juno may be wall mounted or left on its stand (included) to make it portable
- If on its stand it should be placed on table/shelf (securely) 4ft from the ground
- Turn on the Juno at the base of the speaker
- The volume should be set between 14 and 17. This is recommended for the average size classroom. It is not advised to adjust the volume control outside the range above without consulting your Visiting Teacher
- Switch on teacher's microphone and place the mic/transmitter around your neck at collarbone level
- Depress the white section on the base of microphone to turn it on, a green light will be visible
- To temporarily mute the teacher's microphone, simply press the mute button a red light will be visible on the mic, to unmute, press the white section of the mic again
- To use the pass-around microphone, switch on the black switch at the front of the mic. The pass-around mic enables the contributions of classmates to be heard by the student with hearing loss
- Both microphones can be used at the same time (i.e. you do not have to mute or turn off teacher's microphone to use the pass around microphone)
- The Juno will be of benefit to all students in the class, not just the Deaf/Hard of Hearing students